


# PRODUCT MANUAL



**I. Caution** (The following basic safety precautions should be always complied with)  
Avoid casualties and property loss, please always follow the attentions as the following.

**Prohibition**

**WARNING**  
May cause electric shock or fire hazard.

**INSTALLING**

1. Do not use unsafe plug or power.
2. Do not install the device at the place where children can touch.
3. Do not install the device at the place where can not bear strength and prone result in falling and collapsing.
4. Do not tilt the device.
5. Keep the device away from fire and heat source, prohibit to store flammable and explosive materials around the device.
6. Except for the atomizer, the housing material is not resistant to corrosion.
7. Do not use device in high temperature or wet environment.
8. Do not use inflammable, explosive, corrosive and other hazardous solvents work with the device.

**Note**

May cause personal injury or property damage


**NECESSARY INSTALLING**

1. Ensure the firmness of installation area.
2. Install the device in a ventilative and adequate space.
3. Do not block the sprayer by hand or other obstructions when the device is working.
4. Do not spill water or conductive, corrosive liquid on the device surface or fall inside of the device.
5. Cut off the power in extreme weather environment.

**ATTENTION**


This diffuser is unique for using fragrance oil without mixing water. For a better performance of the perfume in the environment, we recommend only using pure essences.

## II. Product Feature



Voltage: 1.5\*3V / 5V  
Power: 1.2W  
Capacity: 200ml  
Weight: 0.45kg  
Coverage: 200-300m<sup>2</sup>  
Size: 140.5\*65.5\*178mm

## III. Accessories



Atomizer head



Oil tube



Fragrance oil bottle

## IV. How to use the equipment



**01.** Choose your favorite fragrance oil



**02.** Press the device button



**03.** Take out the oil bottle



**04.** Pour the oil into the bottle



**05.** Insert the atomizer into the machine



**06.** Install 3 pcs D size batteries




**07.** Manually control the working program



**08.** Enjoy the fragrance

## V. Operation Introduction

**Attention:** Please use a 5V/1A adapter



- 1. Turn On:** Auto-start on after power on.
- 2. UI interface display when standby:** Current weeks, time, work information, battery power display, Bluetooth connection status display.
- 3. Local time setting:** Long press the "SET" button for five seconds to start the time setting; Press the "↑↓" button to set the hour, press the "SET" button to confirm, Then enter the minute setting, press the "↑↓" button to set the minute, press the "SET" button to confirm, then enter the week setting, press the "↑↓" button to select, press the "SET" button to confirm and end, the system automatically saves the current setting and finish the setting.

## 4. Battery power display:

- ★ one cell power: battery power remaining 20%;
- ★ two cells power: battery power remaining 40%;
- ★ three cells power: battery power remaining 60%;
- ★ four cells power: battery power remaining 80%;
- ★ five cells power: battery power remaining 100%;
- ★ when the battery power is lower than 5%, the device stops working.

## 5. Work time and Scent intensity setting

### Five Working Programs:

- Press the "MODE" button for the first time to enter the first program work time setting (Event on 1), press the "SET" button to start the hour setting, press the "↑↓" button to set the hour, press the "SET" button to confirm; Enter the minute setting, press the "↑↓" button to set the minute, and press the "SET" button to confirm; Enter the day setting, press the "↑" button to select the work day, press the "↓" button to cancel the work day setting, Automatically save and finish the first program working time setting.
- Press the "MODE" button for the second time to enter the first program pause time setting (Event Off 1), press the "SET" button to start the hour setting, press the "↑↓" button to set the hour, press "SET" to confirm, enter the minute setting, press "↑↓" to set the minute, Automatically save and finish the first program working time setting.
- Press the "MODE" button for the third time to enter the first program scent intensity adjustment (Scent Work), press the "↑↓" button to adjust the working seconds; the working seconds range is 5 to 30 seconds, press "↑" once to increase 1 second, press "↓" once to decrease 1 second, the working seconds Setup is complete.
- Press the "MODE" button for the fourth time to enter the first program scent intensity pause adjustment (Scent Pause), the pause seconds range is 90 to 900 seconds, press the "↑↓" button once to adjust for 30 seconds; Within 300-500 seconds, press "↑↓" button once to adjust for 50 seconds; and within 500-900 seconds, press "↑↓" button once to adjust for 100 seconds.
- For the remaining 4 program work time and scent intensity settings, repeat the above steps.

## 6. System reset:

Press and hold the "MODE + SET" button for 5 seconds to restore the device to the factory settings. The first program factory setting is 8.00am to 22.00pm, the scent frequency is 10-120 seconds, and the remaining four program setting are 00.00-00.00, and the scent frequency is 10-120 seconds.

## 7. Turn on/Turn off:

Press and hold the "MODE" button for 5 seconds in the power-on state to power off, the power-off prompt is the [OFF] icon flashing 3 times continuously. The screen

does not display any pattern after shutdown.

In the off state, press and hold the "MODE" button for 5 seconds to turn it on, and the boot prompt is the [ON] icon flashing three times in a row.

## VI. Fault Inspection

No scent	<ol style="list-style-type: none"> <li>1. Check whether the device's battery or powered on or not.</li> <li>2. Check whether the pump is working or not and whether the nozzle is blocked or not.</li> <li>3. Check whether the essential oil in the bottle is out or not and whether the pipe falls off or not.</li> </ol>
Oil leakage	<ol style="list-style-type: none"> <li>1. Oil leakage inside the machine: Check whether the essential oil bottle is tightened or not.</li> <li>2. Oil leakage from the mist outlet: Check whether there are obstacles in the mist outlet hole.</li> </ol>
Unusual noise	<ol style="list-style-type: none"> <li>1. Check pump whether fall out, and re-install the air pump.</li> <li>2. Check whether the mist outlet is blocked by obstacle.</li> <li>3. Check the pump whether is low airflow and low pressure.</li> </ol>

## VII. Warranty and after-sales service

### 1. After-sales service

- (1) Provide free technical solutions and installation process guidance
- (2) Provide free online FAQ consultation and scent-marketing suggestion

### 2. Equipment warranty and attentions

- (1) All devices enjoy 12 months free maintenance (from the day of purchase).
- (2) Please provide the warranty card, invoice or other proof which can prove it ordered from our company to enjoy the free maintenance
- (3) The human error or other wrong operation cause the fault not belong to the scope of warranty, and will not be accepted to provide free maintenance.

## VIII. Machine Maintenance

1. Please clean the equipment periodically, suggest 2-3 months in 1 circle, so that it can work under best condition.
2. Please cut off the power when cleaning, also do not use wet hand to operate it directly, in case of electric shock and injury.

## IX. Long-term non-use

- (1) Please turn off and cut off the power then roll up the power cord.
- (2) Clean the filter components.
- (3) Place the deodorant package which contains activated carbon in the device or package, to prevent residual substances in the equipment product odor.
- (4) Please equip the machine with the dust cover, placed in the shade, ventilative place.